

Variation of gluten quality- and quantity-induced changes via the gluten structure in relation to viscoelastic properties



P. Chompoorat^{1,2}, Z. Hernandez^{2,3}, P. Rayas-Duarte²

Maejo University, Chiang Mai, Thailand¹

Oklahoma State University, OK, USA²


Instituto Tecnológico de Veracruz, Veracruz MX³

4th ICC Latin American Cereals Conference, Mexico city



GLUTEN VISCOELASTIC NETWORK

Proteins in fully developed dough stained with Coomassie Blue



Crumb texture

Gas retention


- Wheat industry uses gluten as an additive to adjust flour functionality
- For adjusting processing, texture and shelf life properties

COMPRESSION-RECOVERY ANALYSIS


Large deformation 8 N



- ❖ Gluten compression recovery
- ❖ Novel, rapid and accurate method
- ❖ Uncomplicated equipment
- ❖ Axial deformation




COMPRESSION-RECOVERY TEST





CREEP-RECOVERY ANALYSIS

Small deformation 100 Pa




- ❖ Rheometer
- ❖ Accurate and sophisticated equipment
- ❖ Mechanical model representation



(Bockstaele, 2011)

OBJECTIVE

- **To investigate the effect of gluten products substitution on rheological properties of gluten from commercial flour**



MATERIAL & METHODS

Four gluten products




Level substitution

3% and 6%

Ratio (w/w) 97:3 & 94:6
flour:gluten

**Six commercial flours
with 11% protein (14% mb)**



Extract wet gluten

AACCI method 38-12-02
2% NaCl Solution

METHODS

Properties Measurement and Statistical Analysis

COMMERCIAL GLUTEN AND FLOURS

- ✓ pH
- ✓ **Gluten composition**
- ✓ Capillary electrophoresis
 - polymeric proteins
- ✓ RP-HPLC – monomeric proteins

RHEOLOGICAL TEST **GLUTEN SUBSTITUTION** **AT 3 AND 6%**

- ✓ Large Compression-recovery test (8N)
- ✓ Small deformation Creep-recovery test (100Pa)
- ✓ Experimental data fitted into Burgers model


STATISTICAL ANALYSIS

- ✓ Multivariate test
 - Redundancy Analysis by ordination

RESULTS

Charge to mass ratio of polymeric protein - glutenin

Electropherogram form CE



A: LMW-GS

B: HMW-GS
Y-type

C: HMW-GS
X-type

Luccia et al. (2009)

RESULTS

Properties of gluten and commercial flours

Samples	pH	Capillary electrophoresis			
		Area (%) of total glutenin fractions			
		A	B	C	B/C
		LMW-GS	Y-Type	HMW-GS X-Type	
GA	5.2c	57.4a	17.9e	9.0c	2.0c
GB	4.2d	29.7d	47.6b	0.0e	n/a
GC	5.5b	13.9e	62.0a	13.1b	4.7b
GD	5.2c	48.0b	37.6c	7.5d	5.0a
Commercial flours	5.8a	46.1c	35.2d	18.7a	1.9c


- ✓ GB had more acidity
- ✓ GA and GC had high in glutenin fraction
- ✓ GB and GD had low in x-type

RESULTS


Surface hydrophobicity of Monomeric Proteins - Gliadins

Electropherogram form RP-HPLC

Gluten products



Commercial flours




Flour A and E
53% higher in β & γ - gliadin


RESULTS

Compression-recovery vs. Creep-recovery test
(Large deformation) (Small deformation)

As an example of 6% gluten substitution: Flour A



Recovery phase




Creep-recovery test

RESULTS

Redundancy analysis (RDA)

Elastic/Strength effect




Deformation/
Softening effect

- ✓ GA: high in LMW-GS
- ✓ GB: no x-type and pH

- ✓ GC: high in y-type
- ✓ GD: low in x-type

CONCLUSION

- Substitution with different gluten products impacted **strength and softening effect**.
 - Compression- recovery test was able to **discriminate better** based on **gluten strength**; small deformation separate better on **gluten extensibility**.
 - Substitution with gluten (A and C) **high in LMW-GS and Y-type of HMW-GS** positively correlated with **strength effect**.
 - Substitution with gluten (B and D) **low in X-type of HMW-GS** positively correlated with **softening effect**.
 - Gluten **B with no in X-type of HMW-GS and lowest pH (pH 4.2)** increased **deformation** with level substitution (3 and 6%).
- 



ASANTE
MATUR NUWUN
OBRIGADO
MOCHCHAKKERAM
ARIGATO
KIITOS
DANKON
MULTUMESC
NIRRINGRAZZJAK
MULTUMESC
MOCHCHAKKERAM
TERMA KASHI
WELALIN
KIA ORA
SALAMAT
MATUR NUWUN
MOCHCHAKKERAM
MATONDO
MULTUMESC
CHOKRANE
MAAKE
VINAKA
JUSPAXAR
OBRIGADO
MAAKE
DANKON
ARIGATO
SPASIBO
KIITOS
MERC
KIITOS
MOCHCHAKKERAM
CHOKRANE
MATONDO
MERC
SPASIBO
MATONDO
MAMANA
SALAMAT
MOCHCHAKKERAM
TERMA KASHI
KIITOS
OBRIGADO
SPASIBO
MULTUMESC
MOCHCHAKKERAM
NIRRINGRAZZJAK
GRAZIE
KIA ORA
MATUR NUWUN
OBRIGADO
ASANTE
THANK
YOU